

Operating Instruction for Smart lock HD-403

I. Unlock with fingerprint

Press the fingerprint, when the green light turns on to verify the success with a "drip" sound, represents the lock is opened and the light goes off.

If the verification with the sound of "tick" in three times, at the same time the red light shows red and then turns green, means verification fair.

Please re-verify the fingerprint if the unlock failure.

II. Unlock with password

Touch the keyboard to wake it up, the keyboard light will be on and the fingerprint light turns to green, enter 6-digit password and press # to verify, if the password is correct, the lock will be opened and the light goes off.

If the verification with the sound of "drip" in three times, at the same time the fingerprint light shows red and then turns green, means verification fair.

Please re-verify the password if the unlock failure.

III. Lock Shutting

The lock will be shutting automatic 5 seconds after unlocking.

IV. Adding fingerprint and password

(The first three users are administrators, the fourth or more users are ordinary users)

1. Adding fingerprint for the first time:

Touch the keyboard to wake it up, press "1" and "#", the fingerprint light goes to blue and flashing, press any fingerprints, there will be a long sound "drip" and the blue light stopped flashing, start pressing the fingerprint to be recorded in 5 times. Each time when pressing fingerprint, there will be a "drip" sound, and the green light flashing one time. After 5 times pressing the pingerprint, there will be a long "drip" sound, and the green light turns on, the fingerprint light goes off, which means the operation is successful. (Press 5 different areas of one finger for lock identification in 5 times for better verification)

2. Adding password for the first time:

Touch the keyboard to wake it up, press "1" and "#", the fingerprint light goes to blue and flashing, press any fingerprints, there will be a long sound "drip" and the blue light stopped flashing, enter 6-digit password and press "#" to verify, there will be a "drip" sound and the green light will turns on, enter the 6-digit password again and press the "#" key to confirm. If the entered password is same in twice, it will have same long "drip", and the green light will turns on and goes off, that means successful entering. If there are "drip" sound in three times, and the red light is on and goes off, it means that the password is inconsistent between the two input, that means unsuccessful entering. Please enter again.

3. Adding users for the second time:

Touch the keyboard to wake it up, press "1"+"#", the fingerprint light goes to blue and flashing, verify the entered administrator's fingerprint or password, there will be a long "drip" sound and the blue light stopped flashing, then enter fingerprint or password users according to step 1 or 2.

V. Reset

1. Touch the keyboard to wake it up, enter "888" and press "3" to verify. The red light flashes, verify the entered administrator's fingerprint or password, the light turns green with long "drip" sound, that means successful userdel and factory data reset.

2. Force to restore factory settings: Long press the Settings button 9 seconds on the handle and hold it, the green light flashes with continuous "drip" sound, after 9 seconds later, the red light flashes, release the button, the light turns green and goes off, indicating that the factory has been restored successfully.

VI. Normally Open Mode

Press the normally open button on the handle for 1 second, the light turns green, release the button with a long "drip" sound, that means it is set to normally open mode. Repeat operation can be switched to normally open mode or automatic locking mode.

1. Close the door lock in normally opening mode

Touch the keyboard to wake it up, press "#" to close the lock, or enter the recorded fingerprint or password can also close the lock, and also turn off normally open mode.

VII. Auxiliary Function

1. Press the setting button on the back handle for 1 second and verify the administrator's fingerprint or password, and you can quickly add users;

2. This product has the function of anti-peeping: when entering the password, you can add any numeral garbled code before or after the valid password, and still can open the door. But the total length of the password input can not be longer than 12 digits

3. Press the "#" key for 3 seconds to exit the menu and enter the hibernation state;

VIII. Basic Parameters

1. Number of fingerprint: 50 fingerprints

2. Number of password: 100 groups

3. Power Supply: 4*AAA (1.5V) batteries.

IX. Tips

1. Please store your mechanical keys outside for emergency use

2. When the battery power of the door lock is insufficient, it can also be opened about 50 times, and the red light will flicker

When the battery of the door lock has run out of power, you can open the door through the mechanical key or by input power with power bank.

คำแนะนำการใช้งานสำหรับ Smart lock HD-403

I. ปลดล็อกด้วยลายนิ้วมือ

กดลายนิ้วมือ เมื่อไฟสีเขียวเปิดขึ้นเพื่อยืนยันความสำเร็จด้วยเสียง "หยด" แสดงว่าล็อกเปิดอยู่และไฟดับลง

หากการตรวจสอบด้วยเสียง "ขีด" สามครั้งพร้อมกันไฟสีแดงเป็นสีแดงแล้วเปลี่ยนเป็นสีเขียวหมายความว่าตรวจสอบถูกต้อง โปรดขึ้นชั้นลายนิ้วมืออีกครั้งหากการปลดล็อกล้มเหลว

II. ปลดล็อกด้วยรหัสผ่าน

แตะแป้นพิมพ์เพื่อปลุก ไฟแป้นพิมพ์จะสว่างและไฟลายนิ้วมือเปลี่ยนเป็นสีเขียว ป้อนรหัสผ่าน 6 หลัก แล้วกด # เพื่อยืนยัน หากรหัสผ่านถูกต้อง ล็อกจะเปิดขึ้นและไฟดับลง

หากการตรวจสอบด้วยเสียง "หยด" สามครั้ง ในเวลาเดียวกันไฟลายนิ้วมือเป็นสีแดงและเปลี่ยนเป็นสีเขียว แสดงว่าการตรวจสอบถูกต้อง โปรดขึ้นชั้นรหัสผ่านอีกครั้งหากการปลดล็อกล้มเหลว

III. ล็อกการปิด

ล็อกจะปิดอัตโนมัติ 5 วินาทีหลังจากปลดล็อก

IV. การเพิ่มลายนิ้วมือและรหัสผ่าน

(ผู้ใช้สามคนแรกคือผู้ใช้หลัก ผู้ใช้ที่สี่ขึ้นไปคือผู้ใช้ทั่วไป)

1. เพิ่มลายนิ้วมือครั้งแรก:

แตะแป้นพิมพ์เพื่อปลุก กด "1" และ "#" ไฟลายนิ้วมือเปลี่ยนเป็นสีน้ำเงินกะพริบ กดลายนิ้วมือใดๆ จะมีเสียงยาว "หยด" และไฟสีน้ำเงินหยุดกะพริบ เริ่มกดลายนิ้วมือ ที่จะบันทึกไว้ใน 5 ครั้ง ทุกครั้งที่กดลายนิ้วมือจะมีเสียง "หยด" และไฟสีเขียวกะพริบหนึ่งครั้ง หลังจากกดลายนิ้วมือ 5 ครั้งแล้วจะมีเสียง "หยด" ยาว ๆ และไฟสีเขียวจะสว่างขึ้นและไฟลายนิ้วมือจะดับลงซึ่งหมายความว่าการทำงานสำเร็จ (กด 5 ส่วนที่แตกต่างกันของนิ้วเดียวเพื่อระบุตัวล็อกใน 5 ครั้งเพื่อการตรวจสอบที่สี่ขึ้น)

2. เพิ่มรหัสผ่านครั้งแรก:

แตะแป้นพิมพ์เพื่อปลุก กด "1" และ "#" ไฟลายนิ้วมือเปลี่ยนเป็นสีน้ำเงินกะพริบ กดลายนิ้วมือใด ๆ จะมีเสียง "หยด" ยาว และไฟสีน้ำเงินหยุดกะพริบ ป้อนตัวเลข 6 หลัก รหัสผ่านและกด # เพื่อยืนยัน จะมีเสียง "หยด" และไฟสีเขียวจะเปิดขึ้น ป้อนรหัสผ่าน 6 หลักอีกครั้งแล้วกดปุ่ม "#" เพื่อยืนยัน หากรหัสผ่านที่ป้อนซ้ำกันสองครั้ง จะมี "หยด" ยาวเท่ากัน และไฟสีเขียวจะเปิดขึ้นและดับลง ซึ่งหมายความว่าป้อนสำเร็จ หากมีเสียง "หยด" ในสามครั้ง และไฟสีแดงติดและดับลง แสดงว่ารหัสผ่านไม่สอดคล้องกันระหว่างอินพุตทั้งสอง หมายความว่าป้อนไม่สำเร็จ กรุณาป้อนอีกครั้ง

3. เพิ่มผู้ใช้เป็นครั้งที่สอง:

แตะแป้นพิมพ์เพื่อปลุก กด "1"+"#" ไฟลายนิ้วมือเปลี่ยนเป็นสีน้ำเงินและกะพริบ ตรวจสอบลายนิ้วมือหรือรหัสผ่านของผู้ดูแลระบบที่ป้อน จะมีเสียง "หยด" ยาว และไฟสีน้ำเงินหยุดกะพริบ จากนั้นป้อนผู้ใช้ลายนิ้วมือหรือรหัสผ่านตามขั้นตอนที่ 1 หรือ 2

V. รีเซ็ต

1. แตะแป้นพิมพ์เพื่อปลุก ป้อน "888" แล้วกด "3" เพื่อยืนยัน ไฟสีแดงกะพริบ

ตรวจสอบลายนิ้วมือหรือรหัสผ่านของผู้ดูแลระบบที่ป้อน ไฟจะเปลี่ยนเป็นสีเขียวพร้อมเสียง "หยด" ยาวๆ ซึ่งหมายถึง Userdel ที่ประสบความสำเร็จและการรีเซ็ตข้อมูลเป็นค่าเริ่มต้น

2. บังคับให้คืนค่าการตั้งค่าจากโรงงาน: กดปุ่มการตั้งค่าค้างไว้ 9 วินาทีที่ด้ามจับค้างไว้ ไฟสีเขียวจะกะพริบพร้อมเสียง "หยด"

อย่างต่อเนื่อง หลังจาก 9 วินาทีต่อมา ไฟสีแดงจะกะพริบ ปลดปุ่ม ไฟจะเปลี่ยน สีเขียวและดับลง แสดงว่าโรงงานได้รับการฟื้นฟูสำเร็จแล้ว

VI. โหมดเปิดเสมอ

กดปุ่มเปิดตามปกติที่ด้ามจับเป็นเวลา 1 วินาที ไฟจะเปลี่ยนเป็นสีเขียว ปุ่มพร้อมเสียง "หยด" ซาวๆ ซึ่งหมายความว่าด้ามจับเป็นโหมดเปิดตามปกติแล้ว สามารถสลับการทำงานซ้ำเป็นโหมดเปิดปกติหรือโหมดล๊อคอัตโนมัติได้

1. ปัดล๊อคประตูในโหมดเปิดตามปกติ

แตะแป้นพิมพ์เพื่อปุ่ม กด "#" เพื่อปัดล๊อค หรือป้อนเลขนิ้วมือหรือรหัสผ่านที่บันทึกไว้ ยังสามารถปัดล๊อค และปิดโหมดเปิดตามปกติ

VII. ฟังก์ชันเสริม

1. กดปุ่มตั้งค่าที่ด้ามจับด้านหลังเป็นเวลา 1 วินาที และตรวจสอบเลขนิ้วมือหรือรหัสผ่านของผู้ดูแลระบบ และคุณสามารถเพิ่มผู้ใช้ได้อย่างรวดเร็ว
2. ผลิตภัณฑ์นี้มีฟังก์ชันป้องกันการแอบดู: เมื่อป้อนรหัสผ่าน คุณสามารถเพิ่มรหัสที่อ่านไม่ออกเป็นตัวเลขก่อนหรือหลังรหัสผ่านที่ถูกต้อง และยังสามารถเปิดประตูได้ แต่ความยาวรวมของการป้อนรหัสผ่านต้องไม่เกิน 12 หลัก
3. กดปุ่ม "#" เป็นเวลา 3 วินาทีเพื่อออกจากเมนูและเข้าสู่สถานะไฮเบอร์เนต

VIII. พารามิเตอร์พื้นฐาน

1. จำนวนเลขนิ้วมือ: 50 เลขนิ้วมือ
2. จำนวนรหัสผ่าน: 100 กลุ่ม
3. แหล่งจ่ายไฟ: แบตเตอรี่ AAA ขนาด 4 * (1.5V)

ทรงเครื่องเคสลับ

1. กรุณาเก็บกุญแจเครื่องกลของคุณไว้ข้างนอกเพื่อใช้ในกรณีฉุกเฉิน
2. เมื่อพลังงานแบตเตอรี่ของล๊อคประตูไม่เพียงพอก็สามารถเปิดได้ประมาณ 50 ครั้งและไฟสีแดงจะกะพริบ
3. เมื่อแบตเตอรี่ของตัวล๊อคประตูหมดพลังงาน คุณสามารถเปิดประตูผ่านกุญแจทางกลหรือโดยไฟอินพุตที่มีแบตเตอรี่สำรอง